

MaxiSYS_Maybach_V1.10 Function List

NOTES:

- This function is supported. ✖ This function may be supported which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2006	MayBach	240	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	
Up to 08/2006	MayBach	240	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	
Up to 08/2006	MayBach	240	Drive	ESM-Electronic selector module	●	●	●	●	●	✖	●	
Up to 08/2006	MayBach	240	Drive	SGR-Radar sensors control unit	●	●	●	●	●	●	○	
Up to 08/2006	MayBach	240	Drive	DTR-Distronic	●	●	●	●	●	✖	○	0005
Up to 08/2006	MayBach	240	Drive	DTR-Distronic	●	●	●	●	●	●	○	0005
Up to 08/2006	MayBach	240	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	●	●	●	●	●	●	●	0004
Up to 08/2006	MayBach	240	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	○	○	0006 0007 0008
Up to 08/2006	MayBach	240	Chassis	SBC-Right Sensotronic Brake Control	●	●	●	●	●	○		0006 0007 0008 0038 0039
Up to 08/2006	MayBach	240	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●	0014
Up to 08/2006	MayBach	240	Chassis	AIRmatic	●	●	●	●	●	○	✖	0048 0049 0056
Up to 08/2006	MayBach	240	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●	
Up to 08/2006	MayBach	240	Body	CGW-Central gateway	●	●	●	●	●	○	○	0016 0017 0018
Up to 08/2006	MayBach	240	Body	EZS-Electronic ignition switch	●	●	●	●	●	●		
Up to 08/2006	MayBach	240	Body	AB-Airbag	●	●	●	●	●	●	○	0003 0010 0041
Up to 08/2006	MayBach	240	Body	WSS-Weight sensing system	●	●	●	●	●	○	○	0005
Up to 08/2006	MayBach	240	Body	BNS-Vehicle power supply control module	●	●	●	●	●	○	○	
Up to 08/2006	MayBach	240	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	○	●	
Up to 08/2006	MayBach	240	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	○	●	
Up to 08/2006	MayBach	240	Body	Rear SAM 1-Rear signal acquisition and actuation module1	●	●	●	●	●	○	●	
Up to 08/2006	MayBach	240	Body	Rear SAM 2-Rear signal acquisition and actuation module2	●	●	●	●	●	○	●	
Up to 08/2006	MayBach	240	Body	MSS-Special vehicle multifunction control	●	●	●	●	●	○	●	0003
Up to 08/2006	MayBach	240	Body	VBF (Front control panel)-Front control	●	●	●	●	●	○	●	
Up to 08/2006	MayBach	240	Body	HBF (Rear control panel)-Rear control field	●	●	●	●	●	○	●	
Up to 08/2006	MayBach	240	Body	BCG-Remote control(Rear control field)	●	●	●	●	●	○	●	0003
Up to 08/2006	MayBach	240	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	
Up to 08/2006	MayBach	240	Body	CRN-Center roof node	●	●	○	●	●	●	●	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2006	MayBach	240	Body	PSE-Pneumatic system equipment	●	●	●	●	●	○	●	
Up to 08/2006	MayBach	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	0005 0009
Up to 08/2006	MayBach	240	Body	System diagnosis(CAN)	●	●	●	●	●	●		
Up to 08/2006	MayBach	240	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●	
Up to 08/2006	MayBach	240	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	0005
Up to 08/2006	MayBach	240	Information and communication	ICM-Instrument cluster	●	●	●	●	●	○	●	0002
Up to 08/2006	MayBach	240	Information and communication	AGW-Audio gateway (MOST network management diagnosis gateway radio tuner)	●	●	●	●	●	●		0003
Up to 08/2006	MayBach	240	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○	
Up to 08/2006	MayBach	240	Information and communication	Telephone adapter for portable CTET-Telecommunication for telematics services	●	●	●	●	●	●		
Up to 08/2006	MayBach	240	Information and communication	AUDIO	●	●	●	●	●	●		0003
Up to 08/2006	MayBach	240	Information and communication	COMAND or AUDIO	●	●	○	●	●	●		
Up to 08/2006	MayBach	240	Information and communication	NAVI-Navigation system	●	●	○	●	●	●		
Up to 08/2006	MayBach	240	Information and communication	VCS-Voice control system	●	●	○	●		●		
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner	●	●	○	●	●	●		
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●		
Up to 08/2006	MayBach	240	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●		
Up to 08/2006	MayBach	240	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●		
Up to 08/2006	MayBach	240	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○	
Up to 08/2006	MayBach	240	Information and communication	AVC-Audio video controller	●	●	○	●	●	●	●	
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner (REAR)	●	●	○	●	●	●		
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner (rear)	●	●	●	●	●	●		
Up to 08/2006	MayBach	240	Information and communication	CDC-CD changer (REAR)	●	●	○	●	●	●	○	
Up to 08/2006	MayBach	240	Information and communication	KTL-Left headphone transmitter	●	●	○	●	●	○		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2006	MayBach	240	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●	●	●		
As of 09/2006	MayBach	240	Information and communication	AUDIO	●	●	●	●	●	●		0003
As of 09/2006	MayBach	240	Information and communication	COMAND or AUDIO	●	●	○	●	●	●		
As of 09/2006	MayBach	240	Information and communication	NAVI-Navigation system	●	●	○	●	●	●		
As of 09/2006	MayBach	240	Information and communication	VCS-Voice control system	●	●	○	●		●		
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner	●	●	○	●	●	●		
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●		
As of 09/2006	MayBach	240	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●		
As of 09/2006	MayBach	240	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●		
As of 09/2006	MayBach	240	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○	
As of 09/2006	MayBach	240	Information and communication	AVC-Audio video controller	●	●	○	●	●	●	●	
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner (REAR)	●	●	○	●	●	●		
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner (rear)	●	●	●	●	●	●		
As of 09/2006	MayBach	240	Information and communication	CDC-CD changer (REAR)	●	●	○	●	●	●	○	
As of 09/2006	MayBach	240	Information and communication	KTL-Left headphone transmitter	●	●	○	●	●	○		
As of 09/2006	MayBach	240	Information and communication	KTR-Right headphone transmitter	●	●	○	●	●	○		
As of 09/2006	MayBach	240	Information and communication	GPS box	●	●	○	●	●	●	○	
As of 09/2006	MayBach	240	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○	
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●		●	○	
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services MB Info Roadside assistance(USA Canada) Tele diagnosis(ECE)	●	●	●	●		●	○	
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●		●	○	
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services Remote door unlocking Remote door locking	●	●	●	●		●	○	
As of 09/2006	MayBach	240	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	○	●	

Special_Function

Index	Specil Function Name	Index	Specil Function Name
0001	ASSYST Setting	0002	Service Reset
0003	Read coding and change if necessary.	0004	Variant coding
0005	Initial startup	0006	Deactivate system
0007	Activate system	0008	Customer complaints (without fault codes)
0009	Control unit adaptations	0010	Chassis number
0011	Sliding/tilting roof	0012	Calibration of the torque sensor
0013	Learning of the throttle valve stop	0014	Road test
0015	Tire pressure loss warner (Activating)	0016	Vehicle data
0017	Modification year or model year	0018	All codes
0019	Replace component Diesel particulate filter	0020	Reprogram diesel particulate filter in control unit N3/9 (CDI control unit)
0021	Teach in component Y94 (Quantity control valve)	0022	Teaching in the diesel particulate filter after replacing the engine control unit
0023	Teach-in process after replacement of component Diesel particulate filter	0024	Teaching in the diesel particulate filter after replacing the engine control unit
0025	Activate fuel pump	0026	Rapid teach-in of zero quantity calibration values
0027	Initial startup of control unit EZS	0028	Initial startup of control unit ESL
0029	Disable key or key track	0030	Once again authorize key or key track.//
0031	Once again authorize key or key track.//	0032	Program replacement keys
0033	Activate control module N73 (EIS [EZS] control unit).	0034	Activate control module N26/5 (Electric steering lock control module)
0035	Key assignment or key track assignment to a memory block number	0036	Writing of the VIN
0037	Telematic service 'Remote door unlocking' (TELE AID)	0038	Brake counter update and recalculate lifetime
0039	Replace hydraulic brake system fluid./Bleed brake system.	0040	Zero point variation steering angle and lateral acceleration sensor
0041	Steering variant	0042	Pneumatic tests
0043	Initial test/ Oil condition check/ Oil level check	0044	Diagnosis routines
0045	Calibration of compnent B24/12(ABC lateral acceleration sensor)	0046	Calibration of the plunger travel sensors
0047	Erase zero point offset error of component N49 (Steering angle sensor)	0048	Initial startup with automatic takeover of settings of previous control unit
0049	Initial startup with manual settings input for new control unit/Level calibration	0050	Initializing:Rain sensor,Steering column module
0051	Level calibration	0052	Load adjustment
0056	Pneumatic test of component A9/1 (AIRmatic compressor unit)	0057	Pneumatic test of component A9/1y1 (AIRmatic pressure release valve)
0058	Replacement of control module N80(Steering column	0059	Reset compressor operating time
0060	Reset of calibration	0062	Prevention of diesel particulate filter
0064	Diesel particulate filter New Initializing	0065	Diesel particulate filter Purge control
0066	Diesel particulate filter Used Program	0067	Initializing Diesel particulate filter
0071	Purge control Diesel particulate filter	0073	Regeneration of diesel particulate filter
0074	Regeneration of diesel particulate filter when driving	0075	Replacement of component Diesel particulate filter on left
0076	Replacement of component Diesel particulate filter on right	0077	Teach-in of diesel particulate filter after replacement of engine control unit without
0078	Activate function 'Tire pressure loss warning'	0079	Write identification numbers of tire pressure
0080	Teach in of throttle valve stop		