

## Lambda Sensor Remover/Installer 22mm

Essential two piece tool for removing stubborn Lambda Sensors



### Additional Information

- Designed to allow the use of an Air Hammer to loosen stuck 22mm Lambda sensors
- 200mm reach to give excellent Air Hammer access
- The perfect addition to Laser Air Hammer 6031/6077
- 3/8" D head which allows the use of a torque wrench when tightening sensors
- Use Air Hammer for extraction only, for fitting use 3/8" D tool

<http://lasertools.co.uk/product/6098>

Video available: <https://youtu.be/FVqBPT8cUeI>

